


Operation Manual

Heavy-Duty

2 Hole Punch

Model No. : DP-200




SPC Co., Ltd.

#769-5 WONSI-DONG, ANSAN-SI KYUNGGI-DO, KOREA http://www.spc-punch.co.kr

Tel: 82-31-495-8724 Fax: 82-31-495-8727


http://www.spc-punch.co.kr SPC Co., Ltd.

1. PARTS NAME



2. HOW TO OPERATE


1) Setting papers



•Raise the handle After raising the handle, insert papers completely upright.

 After setting papers on the table, push the to the end of table.


paper guide toward



2) Punching papers •Press the handle down firmly using two hands.


•Lift up the handle slowly to the top.

3) Rotating & Replacing Disks




 While operating, unless perforating turned little by little, plastic disks should be ability should come

base and fit new disks them, simply push up them from bottom of In case of replacing down.



4) Emptying the Chip Tray



 Chip tray should be clean periodically.


5) How to replace punching Bits.


(i) Caution: Before placing the plastic disk


in the position, make sure to sweep the paper


scraps away on the position.

• After extended use, the punching bit becomes dull and requires extra pressure to punch. At this point, the punching bit should be replaced as follows.









- •After removing the rubber cap on the cover, loosen the screw with a screwdriver and remove the cover.
- •Loosen the screw in the front part of punch holder with the hexagonal wrench, which locates on the back of the cover. You can pull down the punching bit.
- •Replace the punching bit with the new one and assemble in reverse order.

CAUTION! READ PRIOR TO USE.

- Always use the machine in standing position and push firmly to ensure that the bit goes completely through the stack of papers.
- Make sure clips or staples are removed before punching, otherwise the bit will be damaged.
 Raise the handle completely upright before setting the papers.
- •Punching bits are very sharp KEEP FINGERS AWAY FROM THE PUNCHING AREA Periodic maintenance should be performed as follows.
- Replace bits and disks regularly for the best results.
- Clean paper dust from the table and waste chips regularly. Rotate disks at regular intervals.
- % For improvement, above specifications can be changed without pre-notice.